

# PV DC FUSE

DC Fuse mainly used in DC combiner box in solar PV systems. When PV panel or inverter causes overload or short circuit, it trip off immediately, to protect PV panels. DC fuse also used to protect other electrical parts in DC circuit, when overload or short circuit.

Nylon shell, resistant to high temperatures



Maximum current 400A maximum voltage DC1200V



